

THE ELECTRIC CIRCUIT FEATURES :

1、When in Nuetral gear, parking,brake, electric start is available.

2、When in R position，Switch of R position is connect to the ground and make the R position light connect to the ground and the light works，at the same time it provide the limit signal to ECU.

3、Function of diodes in this circuit is to make electric start available under rear brake and parking position.

4、The general fuse box is used, every working circuit is independent, it is very easy to maintain the vehicle. Furthermore, there is no joints between the same functional cable, which can ensure there is no phenomenoe connection inside the cable.

WIRING DIAGRAM SSV HSUN RS8 BEFORE 2013